WOOD/COAL BURNING STOVE SUPPLEMENTAL INSPECTION FORM			Insured's Nam	e		Policy No.
Stove/Furnace Unit	Туре	Open Hearth (No doors)	Pot Belly, B			itting, draft-limiting doors and seams)
	Construction	☐ Sheet Metal	☐ Cast Iron	☐ Brick Lined	Any Cracks or B	Broken Parts? ☐ Yes ☐ No
	Fuel	□Wood] Coal	☐ Other (specify):		
	Principal Use	☐ Primary Heat Source (More than 50 days/yr.)		Supplemental Heating (Less than 50 days/yr.)		☐ Cooking
	Installed By	Owner	rner Contractor Month/Year of Installation		on	
	Inspected By	☐ Building Inspector ☐ Fire Department ☐ Other (specify):				
Recomm- dations Chimney/Chimney Connector (Stove Pipe)	Installation	Stove placed at least 36" from combustible well or furnishings, or 18" from non-combustible shield with 1" air space to combustible wall.		Non-combustible pad or surface below stove, extends at least 18" beyond loading door and 12" beyond side and rear.		Stove legs allow at least 4" air space below stove.
		☐ Yes [☐ No	☐ Yes	☐ No	☐ Yes ☐ No
	Туре	☐ Masonry ☐ U.L. Listed Metal Chimney				
	Cleaned/ Inspected	When last cleaned (Mo./Yr.)		Last inspected (Mo./Yr.)		Are ashes disposed of in a fireproof container? Yes No
	Installation	Passes through non-combustible thimble collar or opening which is at least 12" larger in diameter than stove pipe:		Connector to chimney under 10' in length:		Galvanized steel pipe:
		☐ Yes ☐ No		☐ Yes [□ No	☐ Yes ☐ No
		More than two bonds:		Horizontal portion ris per linear ft. of pipe I chimney connection than stove end:	ength so	Pipe sections overlap to contain creosote flowback:
		☐ Yes ☐	No	☐ Yes [□ No	☐ Yes ☐ No
Recomm- dations						

